

1 Preparation



Display warning sign.

2



Check equipment, especially plug and cable. Report any fault or damage to a supervisor.

3



Open the lid.

4



Ensure filters are in place and clean.

5



Apply vacuum lid and connect the hose to the machine.

6



Apply tools to the hose.

7 Operation



Plug in main cord.

8



Work with the cable flat on the floor, not taut.

9 Maintenance



Coil cable around tidy wiping clean with damp cloth as you do.

10a




Remove filters and tools and rinse them with clean water.

10b



10c



11



Store machine.

